



كشف الاجهزة متنوعة اضاءة وصوت وشاشات لمس واشياء متنوعة ومختلفة للحفلات



الرقم number	الاسم name	صورة 1 photo 1	صورة 2 photo 2	صورة 3 photo 3
1.				55551088 77881088 66556393
2.	White light tree			
3.	Blue light tree			

4.	Green light tree			
5.	Red light tree			55551088 77881088 66556393
6.	Black Chroma screen			

7.	LED curtain			
8.	55551088 77881088 66556393			
9.	LED wall washer			

10.	XINGCHEM Profession light			
11.	Smoke machine			55551088 77881088 66556393
12.	Laser light			

13.	Laser light			
14.	Laser light			55551088 77881088 66556393
15.	Focus light			

16.	LEO/S 94-E 40 Flasher light			
17.	Unknown			55551088 77881088 66556393
18.	STAGE LIGHTING			

19.	SMOKE MACHINE			
20.	MING ZHU Focus Light			55551088 77881088 66556393
21.	XINYU - Cloth Fire Serial no: xxx			

22.	Sunflower LED Light			
23.	Sunflower LED Light big			55551088 77881088 66556393
24.	Sunflower LED Light			

25.	Serial lights			
26.	Laser light			55551088 77881088 66556393
27.	Laser light			


28.	Disco lights			
29.	Laser light Round			55551088 77881088 66556393
30.	Digital par lights			

31.	Light clamps			
32.	XINYU Light			55551088 77881088 66556393
33.	STAGE LIGHTING SPM300			



34.	WEN light			
35.	Disco light big			55551088 77881088 66556393
36.	Disco lights small			


37.	Laser light			
38.	Wall light			55551088 77881088 66556393
39.	Beam light 200			

40.	ASIASTAR 575 SPOT 575W			
41.	HMI 1200 FOLLOW SPOT CONTROLLER			55551088 77881088 66556393
42.	Focus light			

43.	Bubble blower			55551088 77881088 66556393
44.	Projector screen & stand			
45.	Projector screen 3*4			

46.	Projector stand and screen			
47.	Projector screen			
48.	SANYO XGA PROJECTOR			55551088 77881088 66556393


49.	MAIEN Speaker Big			
50.	MAIEN Speaker small			
51.	Yamaha R215 speaker			55551088 77881088 66556393

52.	JB1 JRX 100 Model: JRX115 Amp power: 250-500 watts & stand	 	
53.	Gee pass speaker with mic	 	55551088 77881088 66556393
54.	Philips headphone		

55.	Philips headphone			
56.	M audio headphone			55551088 77881088 66556393
57.	Headphone			


58.	SONY - Dynamic Stereo Headphone			Audio Technica ATH-M30 1
59.	SHURE - SRH240A			55551088 77881088 66556393
60.	Shafaghtos speaker With mic			

61.	Proel WD12A			
62.	Proel WD10A			55551088 77881088 66556393
63.	DVD Receiver System - Slim Speaker HT 965TZ			


64.	M-AUDIO – BX5a			55551088 77881088 66556393
65.	Speaker wooden finish			
66.	Lexicon			

67.	MAIEN – DC 80 A Amplifier 8 stereo power 800wx2 4stereo power 1200x2 8 bridge power -2000w			55551088 77881088 66556393
68.	Crown amplifier CE1000			
69.	DBX 231 Graphic equalizer			

70.	DBX 232 Stereo 2way/mono 3way cross over			
71.	Max MS 1000 Serial no: XLS 202 500w 230v- 240v ~ 50hz			55551088 77881088 66556393
72.	CROWN Serial no: XLS 202 500w 230v- 240v ~ 50hz			

73.	Speaker cable pin			
74.	Audio jack pin connector			55551088 77881088 66556393
75.	Stereo pin			

76.	Mono jack pin			
77.	RCI pin connector			55551088 77881088 66556393
78.	XLR female connector			

79.	Mono audio jack pin			
80.	Mono to stereo connector			55551088 77881088 66556393
81.	Speaker connectors			

82.	Female XLR pin			
83.	Male XLR pin			55551088 77881088 66556393
84.	Stereo jack pin			

85.	Mono jack pin			
86.	DENON - Sound System Serial no: DN-X500			55551088 77881088 66556393
87.	DDJ SX2 Pioneer DJ controller			


88.	Yamaha			
89.	YAMAHA - Serial no: PSR-A300			55551088 77881088 66556393
90.	Violin			

91.	Drum instrument			
92.	Jack pin mono connector			55551088 77881088 66556393
93.	Shure Mic			

94.	BBS pro sound Wireless Mic set			
95.	Senhessier Wireless Transmitter & Receiver With neck mic			55551088 77881088 66556393
96.	Shure Wireless neck mic			

97.	Senhessier Wireless Transmitter & Receiver With neck mic			
98.	Shure Double wireless hand Microphone			55551088 77881088 66556393
99.	Shure 2 single wireless hand Microphone			

100.	Shure Wireless hand mic			
101.	Senheisser single Wireless Neck mic			55551088 77881088 66556393
102.	Mixer microphone			




103.	Recording microphone			
104.	Mic stand			55551088 77881088 66556393
105.	Mic stand			

106.	Jack Fish			
107.	MAKSR Yamaha			55551088 77881088 66556393
108.	IPad Stand			





109.	IPad Stand			
110.	Yamaha 12 channel Sound mixer			55551088 77881088 66556393
111.	MASCHINE			


112.	MIXING CONSOLE MG24/14FX			
113.	MIXING CONSOLE MG32/24FX			55551088 77881088 66556393
114.	PRO SOUND MIXER 91U			


115.	NATIVE INSTRUMENTS - Mixer PMX- 2403			
116.	M-AUDIO - Project Mix 1/0 Control Surface			55551088 77881088 66556393
117.	BEHRINGER X32 40CHANNELS 25 BUS			

118.	LED light			
119.	Mic			
120.	Touch screen monitor Red 17 inches			55551088 77881088 66556393
121.	Flatron Touch screen monitor Red 17 inches			

122.	Flatron Touch screen monitor Red 19 inches			
123.	Flatron Touch screen monitor Red 19 inches			55551088 77881088 66556393
124.	Touch screen monitor Black 17 inches			
125.	Monitor stand			

126.	Touch screen			
127.	Touch screen 17 inches			
128.	Touch screen 19 inches			55551088 77881088 66556393

129.	Monitor cables			55551088 77881088 66556393
130.	Monitor stand			
131.	Touch screen			

132.				
133.	Touch screen monitor Black 17 inches			55551088 77881088 66556393
134.	stand			

135.	Character costume			
136.	Character costume			
137.	Character costume			55551088 77881088 66556393

138.	Character costume			
139.	Character costume			55551088 77881088 66556393
140.	Character costume			

141.	Character costume			
142.	Character costume			55551088 77881088 66556393
143.	Character costume			

144.	Snazzy clown Costume			
145.	Clown wig			55551088 77881088 66556393
146.	Smurf costume			

147.	Smurf costume			
148.	Angry Bird costume			55551088 77881088 66556393
149.	Trust media Black t-shirt			

150.	Trust media Purple t-shirt			
151.	Trust media Pink t-shirt			55551088 77881088 66556393
152.	Trust media safety jack			

153.	Cameraman jack			
154.	Trust media Blue t-shirt			55551088 77881088 66556393
155.	Trust media grey t-shirt			



156.	Trust media cap			
157.	Cctv camera With LED light			55551088 77881088 66556393
158.	Stage podium			



159.	Stage podium			
160.	Banner			55551088 77881088 66556393
161.	Wheels Big-3 Small-4			

162.	Black folding chair			
163.	Brown folding chair			55551088 77881088 66556393
164.	DVR H264			

165.	LG DR389 DVD Recorder			55551088 77881088 66556393
166.	LG DP822 DVD player			
167.	Notice board stand			

168.	AA size battery charger			
169.	Cctv camera			55551088 77881088 66556393
170.	Table			

171.	Table			
172.	Led wall mount			55551088 77881088 66556393
173.	rope			

174.	rope			55551088 77881088 66556393
175.	Chroma screen			
176.	Air blower			

177.	Air blower			
178.	Kids balloon item			55551088 77881088 66556393
179.	CD pouch			

180.	Mixer box accessories			
181.	Energizer batteries			55551088 77881088 66556393
182.	Silver tape			
183.	Black & decker drill driver			

184.	Pins			
185.	Hitachi impact drill			
186.	Tools box			55551088 77881088 66556393
187.	Tolls box			

188.	Dust bin box			55551088 77881088 66556393
189.				
190.				